


## **Operator's Manual**

# *LN-25* <sup>™</sup> *PR0*



For use with machines having Code Numbers: **11746, 11747** 



Register your machine:

www.lincolnelectric.com/register

Authorized Service and Distributor Locator: www.lincolnelectric.com/locator

#### Save for future reference

Date Purchased

Code: (ex: 10859)

Serial: (ex: U1060512345)

**Need Help? Call 1.888.935.3877** to talk to a Service Representative

Hours of Operation: 8:00 AM to 6:00 PM (ET) Mon. thru Fri.

#### After hours?

Use "Ask the Experts" at lincolnelectric.com A Lincoln Service Representative will contact you no later than the following business day.

#### For Service outside the USA:

Email: globalservice@lincolnelectric.com



■ INTOD76 | Issue Date Mar-18 © Lincoln Global, Inc. All Rights Reserved. THE LINCOLN ELECTRIC COMPANY 22801 St. Clair Avenue • Cleveland, OH • 44117-1199 • U.S.A. Phone: +1.216.481.8100 • www.lincolnelectric.com

## THANK YOU FOR SELECTING A QUALITY PRODUCT BY LINCOLN ELECTRIC.

## PLEASE EXAMINE CARTON AND EQUIPMENT FOR DAMAGE IMMEDIATELY

When this equipment is shipped, title passes to the purchaser upon receipt by the carrier. Consequently, claims for material damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

#### SAFETY DEPENDS ON YOU

Lincoln arc welding and cutting equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation ... and thoughtful operation on your part. DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT. And, most importantly, think before you act and be careful.

## 

This statement appears where the information must be followed exactly to avoid serious personal injury or loss of life.

## 

This statement appears where the information must be followed to avoid minor personal injury or damage to this equipment.

#### KEEP YOUR HEAD OUT OF THE FUMES.

**DON'T** get too close to the arc. Use corrective lenses if necessary to stay a reasonable distance away from the arc.

**READ** and obey the Safety Data Sheet (SDS) and the warning label that appears on all containers of welding materials.

**USE ENOUGH VENTILATION** or exhaust at the arc, or both, to

keep the fumes and gases from your breathing zone and the general area.

**IN A LARGE ROOM OR OUTDOORS**, natural ventilation may be adequate if you keep your head out of the fumes (See below).

**USE NATURAL DRAFTS** or fans to keep the fumes away from your face.

If you develop unusual symptoms, see your supervisor. Perhaps the welding atmosphere and ventilation system should be checked.



## WEAR CORRECT EYE, EAR & BODY PROTECTION

**PROTECT** your eyes and face with welding helmet properly fitted and with proper grade of filter plate (See ANSI Z49.1).

**PROTECT** your body from welding spatter and arc flash with protective clothing including woolen clothing, flame-proof apron and gloves, leather leggings, and high boots.

**PROTECT** others from splatter, flash, and glare with protective screens or barriers.

IN SOME AREAS, protection from noise may be appropriate.

**BE SURE** protective equipment is in good condition.

Also, wear safety glasses in work area **AT ALL TIMES.** 



#### **SPECIAL SITUATIONS**

**DO NOT WELD OR CUT** containers or materials which previously had been in contact with hazardous substances unless they are properly cleaned. This is extremely dangerous.

**DO NOT WELD OR CUT** painted or plated parts unless special precautions with ventilation have been taken. They can release highly toxic fumes or gases.



#### Additional precautionary measures

**PROTECT** compressed gas cylinders from excessive heat, mechanical shocks, and arcs; fasten cylinders so they cannot fall.

**BE SURE** cylinders are never grounded or part of an electrical circuit.

**REMOVE** all potential fire hazards from welding area.

ALWAYS HAVE FIRE FIGHTING EQUIPMENT READY FOR IMMEDIATE USE AND KNOW HOW TO USE IT.









#### **CALIFORNIA PROPOSITION 65 WARNINGS**



**WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects. or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an exposed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

#### For more information go to www.P65 warnings.ca.gov/diesel

WARNING: This product, when used for welding or cutting, produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code § 25249.5 et seq.)



WARNING: Cancer and Reproductive Harm www.P65warnings.ca.gov

#### ARC WELDING CAN BE HAZARDOUS. PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting -ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2-1974. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

#### BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.

# FOR ENGINE POWERED EQUIPMENT.



- 1.a. Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.
- 1.b. Operate engines in open, well-ventilated areas or vent the engine exhaust fumes outdoors.
- 1.c. Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact



with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.

1.d. Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.



- 1.e. In some cases it may be necessary to remove safety guards to perform required maintenance. Remove guards only when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.
- 1.f. Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.
- 1.g. To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.
- 1.h. To avoid scalding, do not remove the radiator pressure cap when the engine is hot.



### **ELECTRIC AND** MAGNETIC FIELDS MAY **BE DANGEROUS**



- 2.a. Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding current creates EMF fields around welding cables and welding machines
- 2.b. EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.
- 2.c. Exposure to EMF fields in welding may have other health effects which are now not known.
- 2.d. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:
  - 2.d.1. Route the electrode and work cables together Secure them with tape when possible.
  - 2.d.2. Never coil the electrode lead around your body.
  - 2.d.3. Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.
  - 2.d.4. Connect the work cable to the workpiece as close as possible to the area being welded.
  - 2.d.5. Do not work next to welding power source.



#### ELECTRIC SHOCK CAN KILL.



- 3.a. The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Do not touch these "hot" parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- 3.b. Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.

In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:

- Semiautomatic DC Constant Voltage (Wire) Welder.
- DC Manual (Stick) Welder.
- AC Welder with Reduced Voltage Control.
- 3.c. In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically "hot".
- 3.d. Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
- 3.e. Ground the work or metal to be welded to a good electrical (earth) ground.
- 3.f. Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
- 3.g. Never dip the electrode in water for cooling.
- 3.h. Never simultaneously touch electrically "hot" parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
- 3.i. When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.
- 3.j. Also see Items 6.c. and 8.





- 4.a. Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Headshield and filter lens should conform to ANSI Z87. I standards.
- 4.b. Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- 4.c. Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.

### **FUMES AND GASES** CAN BE DANGEROUS.



- 5.a. Welding may produce fumes and gases hazardous to health. Avoid breathing these
  - fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone. When welding hardfacing (see instructions on container or SDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and within applicable OSHA PEL and ACGIH TLV limits using local exhaust or mechanical ventilation unless exposure assessments indicate otherwise. In confined spaces or in some circumstances, outdoors, a respirator may also be required. Additional precautions are also required when welding
  - on galvanized steel.
- 5. b. The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.
- 5.c. Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- 5.d. Shielding gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- 5.e. Read and understand the manufacturer's instructions for this equipment and the consumables to be used, including the Safety Data Sheet (SDS) and follow your employer's safety practices. SDS forms are available from your welding distributor or from the manufacturer.
- 5.f. Also see item 1.b.

## WELDING AND CUTTING SPARKS CAN CAUSE FIRE OR EXPLOSION.



- 6.a. Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.
- 6.b. Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to "Safety in Welding and Cutting" (ANSI Standard Z49.1) and the operating information for the equipment being used.
- 6.c. When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- 6.d. Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned". For information, purchase "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", AWS F4.1 from the American Welding Society (see address above).
- 6.e. Vent hollow castings or containers before heating, cutting or welding. They may explode.
- 6.f. Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- 6.g. Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
- 6.h. Also see item 1.c.
- 6.I. Read and follow NFPA 51B "Standard for Fire Prevention During Welding, Cutting and Other Hot Work", available from NFPA, 1 Batterymarch Park, PO box 9101, Quincy, MA 022690-9101.
- 6.j. Do not use a welding power source for pipe thawing.

## CYLINDER MAY EXPLODE IF DAMAGED.

7.a. Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.



- 7.b. Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.
- 7.c. Cylinders should be located:
  - Away from areas where they may be struck or subjected to physical damage.
  - A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- 7.d. Never allow the electrode, electrode holder or any other electrically "hot" parts to touch a cylinder.
- 7.e. Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- 7.f. Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.
- 7.g. Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-I, "Precautions for Safe Handling of Compressed Gases in Cylinders," available from the Compressed Gas Association, 14501 George Carter Way Chantilly, VA 20151.

## FOR ELECTRICALLY POWERED EQUIPMENT.



- 8.a. Turn off input power using the disconnect switch at the fuse box before working on the equipment.
- 8.b. Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.
- 8.c. Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer's recommendations.

#### Refer to http://www.lincolnelectric.com/safety for additional safety information.

#### **Electromagnetic Compatibility (EMC)**

#### Conformance

Products displaying the CE mark are in conformity with European Community Council Directive of 15 Dec 2004 on the approximation of the laws of the Member States relating to electromagnetic compatibility, 2004/108/EC. It was manufactured in conformity with a national standard that implements a harmonized standard: EN 60974-10 Electromagnetic Compatibility (EMC) Product Standard for Arc Welding Equipment. It is for use with other Lincoln Electric equipment. It is designed for industrial and professional use.

#### Introduction

All electrical equipment generates small amounts of electromagnetic emission. Electrical emission may be transmitted through power lines or radiated through space, similar to a radio transmitter. When emissions are received by other equipment, electrical interference may result. Electrical emissions may affect many kinds of electrical equipment; other nearby welding equipment, radio and TV reception, numerical controlled machines, telephone systems, computers, etc. Be aware that interference may result and extra precautions may be required when a welding power source is used in a domestic establishment.

#### Installation and Use

The user is responsible for installing and using the welding equipment according to the manufacturer's instructions. If electromagnetic disturbances are detected then it shall be the responsibility of the user of the welding equipment to resolve the situation with the technical assistance of the manufacturer. In some cases this remedial action may be as simple as earthing (grounding) the welding circuit, see Note. In other cases it could involve construction of an electromagnetic screen enclosing the power source and the work complete with associated input filters. In all cases electromagnetic disturbances must be reduced to the point where they are no longer troublesome.

Note: The welding circuit may or may not be earthed for safety reasons according to national codes. Changing the earthing arrangements should only be authorized by a person who is competent to access whether the changes will increase the risk of injury, e.g., by allowing parallel welding current return paths which may damage the earth circuits of other equipment.

#### **Assessment of Area**

Before installing welding equipment the user shall make an assessment of potential electromagnetic problems in the surrounding area. The following shall be taken into account:

- a) other supply cables, control cables, signaling and telephone cables; above, below and adjacent to the welding equipment;
- b) radio and television transmitters and receivers;
- c) computer and other control equipment;
- d) safety critical equipment, e.g., guarding of industrial equipment;
- e) the health of the people around, e.g., the use of pacemakers and hearing aids;
- f) equipment used for calibration or measurement
- g) the immunity of other equipment in the environment. The user shall ensure that other equipment being used in the environment is compatible. This may require additional protection measures;
- h) the time of day that welding or other activities are to be carried out.

### **Electromagnetic Compatibility (EMC)**

The size of the surrounding area to be considered will depend on the structure of the building and other activities that are taking place. The surrounding area may extend beyond the boundaries of the premises.

#### Methods of Reducing Emissions

#### Mains Supply

Welding equipment should be connected to the mains supply according to the manufacturer's recommendations. If interference occurs, it may be necessary to take additional precautions such as filtering of the mains supply. Consideration should be given to shielding the supply cable of permanently installed welding equipment, in metallic conduit or equivalent. Shielding should be electrically continuous throughout its length. The shielding should be connected to the welding power source so that good electrical contact is maintained between the conduit and the welding power source enclosure.

#### Maintenance of the Welding Equipment

The welding equipment should be routinely maintained according to the manufacturer's recommendations. All access and service doors and covers should be closed and properly fastened when the welding equipment is in operation. The welding equipment should not be modified in any way except for those changes and adjustments covered in the manufacturers instructions. In particular, the spark gaps of arc striking and stabilizing devices should be adjusted and maintained according to the manufacturer's recommendations.

#### Welding Cables

The welding cables should be kept as short as possible and should be positioned close together, running at or close to floor level.

#### **Equipotential Bonding**

Bonding of all metallic components in the welding installation and adjacent to it should be considered. However, metallic components bonded to the work piece will increase the risk that the operator could receive a shock by touching these metallic components and the electrode at the same time. The operator should be insulated from all such bonded metallic components.

#### Earthing of the Workpiece

Where the workpiece is not bonded to earth for electrical safety, not connected to earth because of its size and position, e.g., ships hull or building steelwork, a connection bonding the workpiece to earth may reduce emissions in some, but not all instances. Care should be taken to prevent the earthing of the workpiece increasing the risk of injury to users, or damage to other electrical equipment. Where necessary, the connection of the workpiece to earth should be made by a direct connection to the workpiece, but in some countries where direct connection is not permitted, the bonding should be achieved by suitable capacitance, selected according to national regulations.

#### Screening and Shielding

Selective screening and shielding of other cables and equipment in the surrounding area may alleviate problems of interference. Screening of the entire welding installation may be considered for special applications<sup>1</sup>.

<sup>1</sup> Portions of the preceding text are contained in EN 60974-10: "Electromagnetic Compatibility (EMC) product standard for arc welding equipment."

## TABLE OF CONTENTS

	Section
-	A
•	A
	A
	A
	A
	A
	A
	ew, Socket Head Cap ScrewA
	Vire GuidesA
	A
	B
	A
Power Source to LN-25 <sup>™</sup> Pro Dual P	Power Cable Connection DiagramsA-7 thru A
	Section
	В
	Machine or in this ManualB
Definition of Welding Terms	В
	В
Recommended Processes, Equipmer	nt Limitations, Recommended Power SourcesB
	B-3 thru B
Constant Current Wire Welding	B-4, B
	В
Internal Controls	В
Internal Controls Decription	В
	В
	Section
Factory Installed Equipment	C
	C
	C-2 thru C
Maintenance	Section
	D
•	D
	D
	D-1,D
	Section
	E
Troubleshooting Guide	E-2, E
Wiring Diagram & Dimension Prints	Section

## **TECHNICAL SPECIFICATIONS** – LN-25<sup>™</sup> PRO (K2613-5, K2613-7)

					CURRENT		PUT AMPERES
	15-110 VDC						4A
	RA		UTPL	JT @ 1	04°F (40°C)		
DUTY	CYCLE				· · ·	MPERES	S
60%	rating				4	50	
GEAF	RING - V	VIRE F	EED	SPEE	D RANGE-WI	RE SIZ	ZE
GEARING		GM				FCAV	
GEATING	WFS R	ANGE	WIR	E SIZES	WFS RANGE		WIRE SIZES
Extra torque K2613-7				3 – 1/16" – 1.6mm)	50 – 400 ipm (1.3 – 10.1m/mir	ı)	.030 - 3/32" (0.8 – 2.4mm)
Standard Speed K2613-5				3 – 1/16" – 1.6mm)	50 – 700 ipm (1.3 – 17.7m/mir	ו)	.030 - 5/64 (0.8 - 2.0mm)
HEIGHT				DIME	NSIONS DEPTH		WEIGHT
пеіяні					DEFIN		WEIGHT
14.8 Inches (376 mm) Handle folded c	łown	8.7 Inche ( 221 mm		-	23.2 Inches (589 mm)	3	38 lbs (17 kg)
		TEMP	ERA	<b>TURE</b>	RANGE		
OPERATION: STORAGE:		-40°F to 104°F (-40°C to 40°C) -40°F to 122°F (-40°C to 50°C)					

Thermal tests have been performed at ambient temperature. The duty cycle (duty factor) at 40°C has been determined by simulation.


Duty cycle is based upon the amount of welding performed in a 10 minute period.

**IP23** 



#### SAFETY PRECAUTIONS

## WARNING



• Turn the input power OFF at the disconnect switch or fuse box before attempting to connect or

disconnect input power lines, output cables or control cables. Only gualified personnel should

- perform this installation.
- Do not touch metal portions of the LN-25<sup>™</sup> PRO work clip when the welding power source is on.
- Do not attach the work clip to the wire feeder.
- · Connect the work clip directly to the work, as close as possible to the welding arc.
- Turn power off at the welding power source before disconnecting the work clip from the work.
- Only use on power sources with open circuit voltages less than 110 VDC.

#### LOCATION

For best wire feeding performance, place the LN-25<sup>™</sup> Pro on a stable and dry surface. Keep the wire feeder in a vertical position. Do not operate the wire feeder on an angled surface of more than 15 degrees.

Do not submerge the LN-25<sup>™</sup> Pro.

The LN-25<sup>™</sup> Pro is rated IP23 and is suitable for outdoor use.

The handle of the LN-25<sup>™</sup> Pro is intended for moving the wire feeder about the work place only.

When suspending a wire feeder, insulate the hanging device from the wire feeder enclosure.

#### HIGH FREQUENCY PROTECTION

### CAUTION

Locate the LN-25<sup>™</sup> PRO away from radio controlled machinery. The normal operation of the LN-25™ PRO may adversely affect the operation of RF controlled equipment, which may result in bodily injury or damage to the equipment.

WELD CABLE SIZE

Table A.1 located below are copper cable sizes recommended for different currents and duty cycles. Lengths stipulated are the distance from the welder to work and back to the welder again. Cable sizes are increased for greater lengths primarily for the purpose of minimizing cable drop.

#### ELECTRODE LEAD

The electrode lead is a 4/0 cable.

RE	RECOMMENDED CABLE SIZES (RUBBER COVERED COPPER - RATED 167°F or 75°C)**					
AMPERES	PERCENT	CABLE SIZES F	CABLE SIZES FOR COMBINED LENGTHS OF ELECTRODE AND WORK CABLES			
	DUTY	0 to 50Ft. (0 to15m)	50 to 100Ft. (15 to 30m)	100 to 150 Ft. (30 to 46m)	150 to 200 Ft. (46 to 61m)	200 to 250 Ft. (61 to 76m)
200	60	2	2	2	1	1/0
200	100	2	2	2	1	1/0
225	20	4 or 5	3	2	1	1/0
225	40 & 30	3	3	2	1	1/0
250	30	3	3	2	1	1/0
250	40	2	2	1	1	1/0
250	60	1	1	1	1	1/0
250	100	1	1	1	1	1/0
300	60	1	1	1	1/0	2/0
325	100	2/0	2/0	2/0	2/0	3/0
350	60	1/0	1/0	2/0	2/0	3/0
400	60	2/0	2/0	2/0	3/0	4/0
400	100	3/0	3/0	3/0	3/0	4/0
500	60	2/0	2/0	3/0	3/0	4/0

TABLE A.1

\*\* Tabled values are for operation at ambient temperatures of 104°F(40°C) and below. Applications above 104°F(40°C) may require cables larger than recommended, or cables rated higher than 167°F(75°C).



#### SHIELDING GAS CONNECTION

## A WARNING

CYLINDER may explode if damaged.

Keep cylinder upright and chained to support.

- Keep cylinder away from areas where it may be damaged.
- Never lift welder with cylinder attached.
- Never allow welding electrode to touch cylinder.
- Keep cylinder away from welding or other live electrical circuits.
   BUILD UP OF SHIELDING GAS MAY

HARM HEALTH OR KILL. • Shut off shielding gas supply when not

in use.

• See American National Standard Z-49.1, "Safety in Welding and Cutting" Published by the American Welding Society.

Maximum inlet pressure is 100 psi. (6.9 bar.)

Install the shielding gas supply as follows:

- 1. Secure the cylinder to prevent it from falling.
- 2. Remove the cylinder cap. Inspect the cylinder valves and regulator for damaged threads, dirt, dust, oil or grease. Remove dust and dirt with a clean cloth. DO NOT ATTACH THE REGULATOR IF OIL, GREASE OR DAMAGE IS PRESENT! Inform your gas supplier of this condition. Oil or grease in the presence of high pressure oxygen is explosive.
- 3. Stand to one side away from the outlet and open the cylinder valve for an instant. This blows away any dust or dirt which may have accumulated in the valve outlet.
- 4. Attach the flow regulator to the cylinder valve and tighten the union nut(s) securely with a wrench. Note: if connecting to 100% CO<sub>2</sub> cylinder, insert regulator adapter between regulator and cylinder valve. If adapter is equipped with a plastic washer, be sure it is seated for connection to the CO<sub>2</sub> cylinder.
- 5. Attach one end of the inlet hose to the outlet fitting of the flow regulator. Attach the other end to the welding system shielding gas inlet. Tighten the union nuts with a wrench.

6. Before opening the cylinder valve, turn the regulator adjusting knob counterclockwise until the adjusting spring pressure is released.

A-3

- 7. Standing to one side, open the cylinder valve slowly a fraction of a turn. When the cylinder pressure gage stops moving, open the valve fully.
- 8. The flow regulator is adjustable. Adjust it to the flow rate recommended for the procedure and process being used before making a weld.



#### WIRE DRIVE CONFIGURATION (See Figure A.2) GUN BUSHING, THUMB SCREW AND SOCKET HEAD CAP SCREW

## WARNING




- ELECTRIC SHOCK can kill.
- Turn the input power OFF at the welding power source before installation or changing drive rolls and/or guides.
- · Do not touch electrically live parts.
- When inching with the gun trigger, electrode and drive mechanism are "hot" to work and ground and could remain energized several seconds after the gun trigger is released.
- Do not operate with covers, panels or guards removed or open.
- Only qualified personnel should perform maintenance work.

Tools required:

- 1/4" hex key wrench.
- Note: Some gun bushings do not require the use of the thumb screw.
- 1. Turn power off at the welding power source.
- 2. Remove the welding wire from the wire drive.
- 3. Remove the thumb screw from the wire drive.
- 4. Remove the welding gun from the wire drive.
- Loosen the socket head cap screw that holds the connector bar against the gun bushing.
   Important: Do not attempt to completely remove the socket head cap screw.
- 6. Remove the outer wire guide, and push the gun bushing out of the wire drive. Because of the precision fit, light tapping may be required to remove the gun bushing.
- 7. Disconnect the shielding gas hose from the gun bushing, if required.
- 8. Connect the shielding gas hose to the new gun bushing, if required.


- Rotate the gun bushing until the thumb screw hole aligns with the thumb screw hole in the feed plate. Slide the gun receiver bushing into the wire drive and verify the thumb screw holes are aligned.
- 10. Tighten the socket head cap screw 10 to 14 ft-lbs (13.5 to 19.0 Nm).
- 11. Insert the welding gun into the gun bushing and tighten the thumb screw.






#### PROCEDURE TO INSTALL DRIVE ROLLS AND WIRE GUIDES

## 



- · Do not touch electrically live parts.
- When inching with the gun trigger, electrode and drive mechanism are "hot" to work and ground and could remain energized several seconds after the gun trigger is released.
- Do not operate with covers, panels or guards removed or open.
- Only qualified personnel should perform maintenance work.
- 1. Turn power off at the welding power source.
- 2. Release the idle roll pressure arm.
- 3. Remove the outer wire guide by turning the knurled thumbscrews counter-clockwise to unscrew them from the feed plate.
- 4. Rotate the triangular lock and remove the drive rolls.



- 5. Remove the inner wire guide.
- 6. Insert the new inner wire guide, groove side out, over the two locating pins in the feed plate.

- 7. Install a drive roll on each hub assembly secure with the triangular lock.
- 8. Install the outer wire guide by aligning it with the pins and tightening the knurled thumbscrews.
- 9. Close the idle arm and engage the idle roll pressure arm. Adjust the pressure appropriately.

## 

#### LOADING SPOOLS OF WIRE

• Keep hands, hair, clothing and tools away from rotating equipment.

- Do not wear gloves when threading wire or changing wire spool.
- Only qualified personnel should install, use or service this equipment.

Loading 10 to 15 lb. (4.5 - 6.8kg) Spools.

A K468 spindle adapter is required for loading 2" (51mm) wide spools on 2" (51mm) spindles. Use a K468 spindle adapter for loading 2-1/2" (64mm) wide spools.

- 1. Squeeze the release bar on the retaining collar and remove it from the spindle.
- 2. Place the spindle adapter on the spindle, aligning the spindle brake pin with the hole in the adapter.
- 3. Place the spool on the spindle and align the adapter brake tab with one of the holes in the back side of the spool. An indicator mark on the end of the spindle shows the orientation of the brake tab. Be certain the wire feeds off of the spool in the proper direction.
- 4. Re-install the retaining collar. Make sure that the release bar snaps out and that the retaining collar fully engages the groove on the spindle.



#### PRESSURE ARM and ADJUSTMENT

#### 🛦 WARNING



ELECTRIC SHOCK can kill.

• Turn the input power OFF at the welding power source before installation or changing drive rolls and/or guides.

- · Do not touch electrically live parts.
- When inching with the gun trigger, electrode and drive mechanism are "hot" to work and ground and could remain energized several seconds after the gun trigger is released.
- Do not operate with covers, panels or guards removed or open.
- Only qualified personnel should perform maintenance work.


The pressure arm controls the amount of force the

drive rolls exert on the wire. Proper adjustment of the pressure arm gives the best welding performance. Many welding problems can be attributed to setting the pressure arm too high and causing wire deformation. Set the pressure arm to minimum amount that provides reliable feeding.

Set the pressure arm as follows:

(See Figure A.3)

Aluminum wires	between 1 and 2		
Cored wires	between 1 and 3		
Steel, Stainless wires	between 3 and 5		
FIGURE A.3			



#### **GUN CONNECTION**

### A WARNING



ELECTRIC SHOCK can kill.

Turn the input power OFF at the welding power source before installation or changing drive rolls and/or guides.
Do not touch electrically live parts.


- When inching with the gun trigger, electrode and drive mechanism are "hot" to work and ground and could remain energized several seconds after the gun trigger is released.
- Do not operate with covers, panels or guards removed or open.
- Only qualified personnel should perform maintenance work.

The LN-25<sup>™</sup> PRO comes with a K1500-2 gun adapter installed. (See Figure A.4)

To install a gun,

- 1. Turn power OFF.
- 2. Remove the thumb screw.
- 3. Push the gun the completely into the gun bushing.
- 4. Secure the gun in place with the thumb screw.
- 5. Connect the trigger cable from the gun to the trigger connector on the front of the feeder.
- Note: Not all gun bushings require the use of the thumb screw.

**FIGURE A.4** 






## POWER SOURCE TO LN-25<sup>™</sup> PRO CABLE CONNECTION DIAGRAMS

#### ACROSS THE ARC SET-UPS

## CC Power Sources with Output Terminals Always Hot (See Figure A.5)




If the power source has a Remote/Local switch, place the switch in the Local position.

Place the CV/CC switch in the feeder in the "CC" position.

K#	Description	
K2613-5	LN-25 <sup>™</sup> PRO Wire Feeder	
K2613-7	LN-25 <sup>™</sup> PRO Extra Torque	
KP1695-xx		
KP1696-xx	Drive Roll Kit	
KP1697-xx		
See Magnum Literature	Welding Gun	
	CC power source	
K1803-xx	Welding Cables	

## **CV** Power Sources with Stud Connectors and Remote/Local Switch (See Figure A.6)




Place the power source Remote/Local switch in the Local position.

Place CV/CC switch in the feeder in the "CV" position.

K#	Description
K2613-5	LN-25™ PRO
K2613-7	LN-25 <sup>™</sup> PRO Extra Torque
KP1695-XX	
KP1696-XX	Drive Roll Kit
KP1697-XX	
See magnum Literature	Welding Gun
	CV power Source
K1803-XX	Welding Cables
K484	Jumper Plug Kit




## CV Power Sources with Stud Connectors and no Remote/Local Switch. (See Figure A.7)



Place CV/CC switch in the feeder in the "CV" position.

K#	Description	
K2613-5	LN-25™ PRO	
K2613-7	LN-25™ PRO Extra Torque	
KP1695-XX		
KP1696-XX	Drive Roll Kit	
KP1697-XX		
See Magnum Literature	Welding Gun	
	CC power Source	
K1803-XX	Welding Cables	

## CV Power Source with Twist-Mate Connectors and Remote/Local Switch. (See Figure A.8)



K1841-XX

K852-95


Welding Cables

Twist-Mate Cable Plug



## INSTALLATION

## CV Power Source with Twist-Mate Connectors and no Remote/Local Switch. (See Figure A.9)





## SAFETY PRECAUTIONS

READ AND UNDERSTAND ENTIRE SECTION BEFORE OPERATING MACHINE.

## 



• ELECTRIC SHOCK CAN KILL. Unless using COLD FEED feature, when feeding with gun trigger, the electrode and drive mechanism are always electrically energized and could remain energized several seconds after the welding ceases.

- Do not touch electrically live part or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.
- Do not operate with covers, panels or guards removed or open.



• FUMES AND GASSES can be dangerous.

- Keep your head out of fumes.
- Use ventilation or exhaust to remove fumes from breathing zone.



• WELDING SPARKS can cause fire or explosion.

Keep flammable material away.



ARC RAYS can burn.

• Wear eye, ear and body protection.

SEE ADDITIONAL WARNING INFORMATION UNDER ARC WELDING SAFETY PRECAUTIONS AND IN THE FRONT OF THIS OPERATING MAN-UAL. GRAPHIC SYMBOLS THAT APPEAR ON THIS MACHINE OR IN THIS MANUAL

**B-1** 

Ð	INPUT POWER
	ON
0	OFF
00	WIRE FEEDER
+	POSITIVE OUTPUT
	NEGATIVE OUTPUT
]₽	INPUT POWER
	DIRECT CURRENT
U <sub>0</sub>	OPEN CIRCUIT VOLTAGE
U <sub>1</sub>	INPUT VOLTAGE
U <sub>2</sub>	OUTPUT VOLTAGE
I <sub>1</sub>	INPUT CURRENT
I <sub>2</sub>	OUTPUT CURRENT
	PROTECTIVE GROUND
	WARNING OR CAUTION

#### DEFINITION OF WELDING TERMS

#### WFS

Wire Feed Speed

#### CC

Constant Current

#### CV

Constant Voltage

#### GMAW

Gas Metal Arc welding

#### SMAW

· Shielded Metal Arc welding

#### **FCAW**

Flux Core Arc Welding

### GENERAL DESCRIPTION

#### **General Physical Description**

The LN-25<sup>™</sup> PRO is specially engineered to be the most rugged portable wire feeder available.

Several models of the LN-25<sup>™</sup> PRO are offered to best meet individual welder needs. The Extra Torque model features additional torque gearing for reliable feeding of large diameter FCAW wires. The Standard and Dual Power models feature wire drive gearing for great performance for both FCAW and GMAW wires of common sizes. All of the models include a gas solenoid for the flexibility to run most wire processes.

The plastic case is molded from a high impact, flame retardant plastic for durability and low weight.

The heart of the LN-25™ PRO is the 2 roll MAX-TRAC<sup>™</sup> drive. The patented features on the wire drive offer tool-less changing of the drive rolls and wire guides for guick spool changes. A tachometer controlled motor powers the patented drive rolls for smooth, steady feeding without slippage.

With a 450 amp, 60% duty cycle rating, these feeders are ready for heavy duty welding.

#### **General Functional Description**

All LN-25<sup>™</sup> PRO's have adjustable WFS range for improving the knob sensitivity. The low range is great for critical welds with Innershield wires, and the upper range is suitable for general purpose welding. Selection of the WFS range is by a rocker switch or through the set-up menu on meters with digital displays.

#### RECOMMENDED PROCESSES

- GMAW
- FCAW

#### **PROCESS LIMITATIONS**

- · GMAW-P procedures must be gualified by the customer.
- · Across-the-Arc models are not recommended for stitch or spot welding.

#### EQUIPMENT LIMITATIONS

- The duty cycle of the wire feeder is 450A, 60%. Duty cycle is based upon the amount of welding performed in a 10 minute period.
- The maximum spool size is 45 lb. (24 Kg), 12" (305mm) diameter.
- · Maximum FCAW gun length is 15 ft.
- · Maximum GMAW gun length is 25 ft.
- · K2330-1 Timer Kits do not work with the feeder. Use K2330-2 kits.
- Push-pull guns do not work with the LN-25<sup>™</sup> PRO.
- Not compatible with K489-7 Euro connector (except K2614-7,-8)

#### RECOMMENDED POWER SOURCES

- CV-305
- CV-400
- CV-655
- DC-400
- DC-600
- DC-655
- Invertec V-350
- FlexTec 450
- Multi-Weld 350
- Ranger 10,000


- Ranger 3 Phase
- Ranger 225
- Ranger 225 GXT
- Ranger 250
- Ranger 305
- SAE-400
- Pipeliner 200G
- Classic 300
- Vantage 300
- Vantage 400
- Vantage 500

**B-2** 



(See **Customer Assistance Policy** in the front of this Instruction Manual)

## CASE FRONT CONTROLS (See Figure B.1)



ITEM	DESCRIPTION
1	Analog Voltmeter
2	Wire Feed Speed Knob
3	Wire Feed Speed Range Switch
4	5-pin gun trigger connector
5	Work sense lead
6	Thermal LED, Motor Overload
7	Polarity LED

#### 1. ANALOG VOLTMETER

Reads 0 – 40 VDC and is polarity insensitive. Shows OCV when not welding and arc voltage when welding.

**B-3** 

The serviceability of a product or structure utilizing the LN-25<sup>™</sup> PRO wire feeder is and must be the sole responsibility of the builder/user. Many variables beyond the control of The Lincoln Electric Company affect the results obtained in using the LN-25<sup>™</sup> PRO wire feeder. These variables include, but are not limited to, welding procedure, plate chemistry and temperature, weldment design, fabrication methods and service requirements. The available range of the LN-25<sup>™</sup> PRO wire feeder may not be suitable for all applications, and the builder/user is and must be solely responsible for welding settings.

CV OPERATION				
Minimum Arc Volts		Maximum WFS (Extra Torque )		
15 V	400	220		
17 V	450	250		
21 V	570	300		
24 V	650	350		
27 V	700	400		

#### Wire Feed Speed, CC Operation

When Across the Arc models are operated with CC power sources, the wire feed speed changes as the arc voltage changes. When the arc voltage increases, the wire feed speed will increase; and when the arc voltage decreases, the wire feed speed will decrease.


To preset the wire feed speed on CC power sources:

- 1. Set the Wire Feed Mode switch inside the LN-25<sup>™</sup> Pro to "CC".
- Refer to the Figure B.1a graph for the setting for the wire feed speed knob setting. Select the horizontal line representing the Desired Wire Feed Speed. (See Figure B.1a arrow for 375 in/min.)
- 3. Select the diagonal line representing the Arc Volts. (See Figure B.1a for 29 volts.)
- 4. Determine the vertical line representing the CC representing the CC Wire Feed Speed setting where the above two lines cross. (See Figure B.1a arrow line for 450.) Set the LN-25<sup>™</sup> Pro wire feed speed knob to this value.

 $CC WFS dial setting = \frac{desired WFS \times 35}{Arc Volts}$ 

Example:

- =  $\frac{375 \text{ in/min. (Horizontal Line) x 35}}{29 \text{ Arc Volts (Diagonal Line)}}$
- = 452.5 (Vertical Line) **Use 450** setting (See Figure B.1a)



#### FIGURE B.1a

A constant voltage (CV) power source is recommended for fluxcored arc welding. (FCAW) and gas metal arc welding (GMAW) to obtain code quality results. However, this wire feeder may also be used with a constant current (CC) power source to obtain passable results for noncritical quality applications.

## CONSTANT CURRENT WIRE WELDING

(See Figure B.3)

Most semiautomatic welding processes perform better using constant voltage power sources.

Welding codes usually do not address the power source selection or specifically, whether the welding process is to be operated in the constant voltage or constant current mode. Instead, codes typically specify limitations on the current, voltage, heat input and preheat temperature based on the material to be welded. The intention is to assure that proper weld material properties will develop.


Welding is sometimes performed using constant current power sources. The operation can be more convenient because it may allow the use of an existing stick (SMAW) power source and the power source can be placed at a distant location without any provision for adjusting the output settings.

For constant current operation, the power source is set to deliver the specified current. The power source regulates this current regardless of changes in the welding circuit, including cable length, electrode diameter, wire feed speed, contact tip to work distance, etc.

Changes in the wire feed speed (WFS) or contact tip to work distance (CTWD) affect the arc voltage when constant current power sources are used. Lowering the wire feed speed raises the voltage, raising the wire feed speed lowers the voltage. Lengthening the contact tip to work distance raises the voltage, shortening the contact tip to work distance lowers the voltage. If the contact tip to work distance is properly maintained, a satisfactory operating voltage range may be achieved, and a sound weld may result. However, when a welder uses a longer contact tip to work distance, an arc-sensing wire feeder compensates by increasing the wire feed speed to regulate the voltage. Even if the voltage and current remain unchanged, the increased wire feed speed may result in a deposition rate well beyond the specified range of the electrode. Under these conditions, the specified weld metal properties may not be achieved.

Constant voltage power sources deliver large current surges to stabilize the arc when the electrode is shorted or the arc length is very short. However, a constant current power source does not provide such a response to stabilize the arc. It may be difficult to achieve required weld metal properties, or to achieve the required quality of welds needed to pass nondestructive tests, when such welds are made under constant current operation.

For these reasons, Lincoln Electric does **<u>NOT</u>** recommend constant current semiautomatic welding for applications which need to meet specified weld metal chemical or mechanical property requirements or weld quality requirements.



#### FIGURE B-3



#### 2. WIRE FEED SPEED KNOB

Use the Wire Feed Speed Knob to adjust the rate of wire feed speed.

#### WFS range for standard torque:

High = 50 to 700 ipm Low = 50 to 200 ipm

#### WFS range for extra torque:

High = 50 to 400 ipm

Low = 50 to 200 ipm


Because the wire feeder is powered by the arc voltage, the full range of wire feed speed may not be available at low voltages.

#### 3. WIRE FEED SPEED RANGE SWITCH

Use to select either the low range or high range for the wire feed speed knob. Note – selecting the low range does not increase the torque of the wire drive.

#### 4. 5-PIN GUN TRIGGER CONNECTOR

There is one circular connector for the gun trigger on the front of the LN-25<sup>™</sup> PRO. **Note** – if the gun trigger is already depressed when the feeder is powered up, the feeder will not activate. Release and then press the gun trigger to begin welding.



Function	Pin	Wiring
5-pin trigger	Α	5 volt supply
connector for	В	Not used
push-guns	С	Trigger
only.	D	Not used
	E	Not used

#### 5. WORK SENSE LEAD

Always turn power off at the welding power source before moving the work sense lead.

The work sense lead attaches to the item being welded.

#### 6. THERMAL LED, MOTOR OVERLOAD

The thermal light illuminates when the wire drive motor draws too much current. If the thermal light illuminates, the wire drive will automatically shutdown for up to 30 seconds to allow the motor to cool. To



start welding again, release the gun trigger, inspect the gun cable, liner (and conduit). Clean and make repairs as necessary. Start welding again when the problem has been safely resolved. For best results, keep the gun cable and conduit as straight as possible. Perform regular maintenance and cleaning on the gun liner, conduit and gun. Always use quality electrode, such as L-50 or L-56 from Lincoln Electric.

#### 7. POLARITY LED


The Polarity LED lights when the wire feeder is connected for positive polarity. Use the polarity LED to verify the



wire feeder is connected for the proper polarity.



### **INTERNAL CONTROLS**



ITEM	DESCRIPTION
1	2 Step Trigger Interlock Switch
2	CV / CC Switch
3	Pressure Adjustment Arm
4	Optional Timer Kit
5	Spool Retainer
6	Spindle Brake
7	Gun Bushing, Thumb Screw and Socket Head Cap Screw
8	Drive Hubs
9	Cold Feed Pushbutton



## INTERNAL CONTROLS DESCRIPTION

(See Figure B.2)

#### 1. 2 STEP - TRIGGER INTERLOCK SWITCH

The 2 Step - Trigger Interlock switch changes the function of the gun trigger. 2 Step trigger operation turns welding on and off in direct response to the trigger. Trigger Interlock operation allows welding to continue when the trigger is released for comfort on long welds.



Place the toggle switch in the DOWN position for 2 Step operation or in the UP position for Trigger Interlock operation.

#### 2 Step Trigger

2 Step trigger operation is the most common. When the gun trigger is pulled, the welding power source energizes the electrode output and the wire feeder feeds wire for welding. The power source and wire feeder continue welding until the trigger is released.

#### **Trigger Interlock**

Trigger Interlock operation provides for operator comfort when making long welds. When the gun trigger is first pulled, the welding power source energizes the output and the wire feeder feeds wire for welding. The gun trigger is then released while the weld is made. To stop welding, the gun trigger is pulled again, and when it is released the welding power source output turns off and the wire feeder stops feeding wire.

### 




If the arc goes out while welding with trigger interlock operation, the electrode output from the welding power source remains energized and the wire feeder will continue to feed wire until the gun trigger is again pulled and then released.

#### 2. CV/CC SWITCH

The CV/CC switch sets the wire feed speed control method for the wire feeder.

In the CV position, the wire feed speed remains constant during welding. A steady arc voltage is regulated by the power source by adjusting the arc current.

In the CC position, the wire feed speed varies during welding. The arc length is maintained by changing the wire feed speed.



#### 3. PRESSURE ARM and ADJUSTMENT (SEE INSTALLATION SECTION)

#### 4. OPTIONAL TIMER KIT

The optional Timer Kit provides control of preflow time, burnback, and postflow time.

#### 5. SPOOL RETAINER

To release the spool retainer, squeeze the metal bar inwards. When securing the spool, verify the spool retainer is fully seated in place in one of the three grooves of the spindle.

#### 6. SPOOL BRAKE

Adjust the spool brake to provide enough friction to stop wire overrun. Excessive brake force may cause motor thermal overloads or welding problems.

#### 7. GUN BUSHING, THUMB SCREW AND SOCKET HEAD CAP SCREW (SEE INSTALLATION SECTION)

#### 8. DRIVE ROLLS AND WIRE GUIDES (SEE INSTALLATION SECTION)

#### 9. COLD FEED PUSHBUTTON

When cold feeding, the wire drive will feed electrode but neither the power source nor the gas solenoid will be energized. Adjust the speed of cold feeding by rotating the WFS knob. Cold feeding, or "cold inching" the electrode is useful for threading the electrode through the gun.




#### **REAR CONTROLS:**

(See Figure B.4)

#### 1. GAS PURGE PUSHBUTTON

The gas solenoid valve will energize but neither the power source output nor the drive motor will be turned on. The Gas Purge switch is useful for setting the proper flow rate of shielding gas. Flow meters should always be adjusted while the shielding gas is flowing.



**FIGURE B.4** 

ITEM	DESCRIPTION
1	Gas Purge Pushbutton
2	Shielding Gas Inlet
3	Electrode Lead



### FACTORY INSTALLED EQUIPMENT

• K1500-2 Gun Receiver Bushing.

### **DRIVE ROLL KITS, 2 ROLL DRIVE**

WIRE TYPE	ELECTRODE SIZE	KP KIT		
Steel Wires:	.023030 (0.6-0.8mm)	KP1696-030S		
	.035 (0.9mm)	KP1696-035S		1 1 (SZ 22
	.045 (1.2mm)	KP1696-045S	Includes: 2 V groove	
	.052 (1.4mm)	KP1696-052S	drive rolls and inner	
	1/16 (1.6mm)	KP1696-1/16S	wire guide.	
	.035,.045 (0.9, 1.2mm)	KP1696-1		
	.040 (1.0mm)	KP1696-2		
	.030035" (0.8-0.9mm)	KP1697-035C		
Cored Wires:	.040045" (1.0-1.2mm)	KP1697-045C		AT A A
	.052" (1.4mm)	KP1697-052C	Includes: 2 Knurled	
	1/16" (1.6mm)	KP1697-1/16C	drive rolls and inner	
	.068072" (1.7-1.8mm)	KP1697-068	wire guide.	
	5/64" (2.0mm)	KP1697-5/64		and the second se
(Extra Torque Models only)	3/32" (2.4mm)	KP1697-3/32		
	.035" (0.9 mm)	KP1695-035A		
Aluminum Wires:	.040" (1.0mm)		Includes: 2 polished	
	3/64" (1.2mm)		U groove drive rolls,	
	1/16" (1.6mm)	KP1695-1/16A	outer wire guide and	
			inner wire guide.	

K2330-2	Timer Kit	Includes: Panel and harness for adjusting preflow, burnback and postflow times.	
K2596-2	Plastic Case	Includes: a complete engi- neered plastic case.	
K1796-xx	AWG 1/0 Co-Axial Power Cable	Includes: 1/0 Coaxial weld cable of length "xx". Ends of the weld cable have lug con- nections. Use for Pulse weld- ing.	
K2593-xx	AWG #1 Coaxial Power Cable	Includes: AWG #1 Coaxial weld cable of length "xx". Ends of the weld cable have lug connections. Use for Pulse or STT™ welding.	
K1803-1	Work and Feeder Cables Package	Includes: Twist-Mate to Lug 2/0 cable 14' (1.2m) long with Ground Clamp, and Twist- Mate to Lug 2/0 Cable 9' (2.7m) long.	
K1840-xx	Weld Power Cable, Twist-Mate to Lug	Includes: Twist-Mate to Lug, 1/0 cable of length "xx".	
K1842-xx	Weld Power Cable, Lug to Lug	IIncludes: Lug to Lug, 3/0 Cable of length "xx" for lengths up to 60' (18.3m). Lug to Lug, 4/0 Cable of length "xx" for lengths greater than 60' (18.3m).	



K484	Jumper Plug Kit	Includes: 14 pin circular connector with jumper for leads 2-4. For use in power sources for turning the weld terminals "ON" at all times.	
K910-1	Ground Clamp	Includes: One 300 Amp Ground Clamp.	2C
K910-2	Ground Clamp	Includes: One 500 Amp Ground Clamp.	
K1500-1	Gun Receiver Bushing (for guns with K466-1 Lincoln gun connec- tors; Innershield and Subarc guns)	Includes: Gun receiver bush- ing, set screw and hex key wrench.	



K1500-2	Gun Receiver Bushing (for guns with K466-2, K466-10 Lincoln gun connectors; Magnum 200/300/400 guns and compatible with Tweco® #2-#4)	Includes: Gun receiver bush- ing with hose nipple, set screw and hex key wrench.	
K1500-3	Gun Receiver Bushing (for guns with K613-7 Lincoln gun connec- tors; Magnum 550 guns and com- patible with Tweco® #5)	Includes: Gun receiver bush- ing with hose nipple, set screw and hex key wrench.	
K1500-4	Gun Receiver Bushing (for gun with K466-3 Lincoln gun connec- tors; compatible with Miller® guns.)	Includes: Gun receiver bush- ing with hose nipple, set screw and hex key wrench.	
K1500-5	Gun Receiver Bushing (compatible with Oxo® guns.)	Includes: Gun receiver bushing with hose nipple, 4 guide tubes, set screw and hex key wrench.	
K435	Spindle Adapter, for mounting 14 lb. (6.4 kg) Innershield Coils on 2 in (51 mm) spindles.	Includes: Spindle Adapter made from 2 coil retainers. (Electrode not included.)	
K468	Spindle Adapter, for mounting 8in (203mm) diameter spools on 2 in (51 mm) spindles.	Includes: 2 Spindle Adapters, one for 2" wide spools and the other for 3" wide spools.	
K590-6	Water Connection Kit (for European and Control cable mod- els only)	Includes: 2 hoses with female quick connectors at each end, 2 male connectors for 3/16" ID hose, 2 male connectors for _" ID hose, and mounting hardware.	
K586-1	Deluxe Adjustable Gas Regulator	Includes: Deluxe Gas Regulator for Mixed Gases, Adapter for CO2 and 10' (3.0m) Hose.	
K283	Wire Feed Speed Meter	Includes: A wire feed speed meter with digital display.	

## SAFETY PRECAUTIONS

## 

#### ELECTRIC SHOCK can kill.



- Turn the input power OFF at the welding power source before installation or changing drive rolls and/or guides.
- Do not touch electrically live parts.
- When inching with the gun trigger, electrode and drive mechanism are "hot" to work and ground and could remain energized several seconds after the gun trigger is released.
- Do not operate with covers, panels or guards removed or open.
- Only qualified personnel should perform maintenance work.

#### **ROUTINE MAINTENANCE**

- Check weld cables, control cables and gas hoses for cuts.
- · Clean and tighten all weld terminals.

#### PERIODIC MAINTENANCE

- Clean drive rolls and inner wire guide and replace if worn.
- Blow out or vacuum the inside of the feeder.
- Inspect the motor brushes every 6 months. Replace if shorter than 0.5" (12.7mm).


#### **CALIBRATION SPECIFICATION**

#### VOLTMETER VALIDATION (See Figure D.1)

To verify the analog voltmeter accuracy:

- 1. Turn power OFF.
- 2. Connect the LN-25<sup>™</sup> PRO to the constant voltage DC power supply capable of supply at least 4 amps. Connect the electrode to the "+" positive terminal and the work clip to the "-" negative terminal.
- 3. Connect a reference voltmeter between the brass block of the LN-25<sup>™</sup> PRO and the work lead.
- 4. Turn power ON.
- 5. Energize the power supply. Adjust the power source output to 20.0 VDC as measured on the reference meter.
- 6. Verify that LN-25<sup>™</sup> PRO voltmeter reads 20 volts. Adjust the voltmeter as necessary by turning the screw on the voltmeter.








#### WIRE FEED SPEED VALIDATION

Calibration of the LN-25<sup>™</sup> PRO may be required when the P.C. board, wire feed speed potentiometer or motor is replaced or serviced. Calibration matches the scale on the name plate to the actual wire feed speed.

To calibrate the LN-25<sup>™</sup> PRO:

- 1. Turn power OFF at the welding source.
- 2. Remove the spool of wire and the cover from the feeder. Remove the gun from the feeder plate, leaving the gun trigger attached to the feeder. Remove the plastic cover on the feed plate to reveal the motor gear.
- 3. Place the WFS range switch in the "high" setting. Set the WFS knob to
  - 50 ipm for K2613-5
  - 25 ipm for K2613-7
- 4. Trigger the LN-25<sup>™</sup> PRO and measure the rpm of the motor gear. Adjust the WFS knob as required until the rpm measures 8.9 to 9.2 rpm.
- 5. Insert the shorting plug into the control board for 1 second and then remove the shorting plug. The shorting plug shorts pins 4 and 7 of J3.
- 6. Set the WFS knob to
  - 800 ipm for K2613-5
  - 400 ipm for K2613-7
- 7. Trigger the LN-25<sup>™</sup> PRO and measure the rpm of the motor gear. Adjust the WFS knob as required until the rpm measure 128.0 to 130.0 rpm.
- 8. Insert the shorting plug into the control board for 1 second and then remove the shorting plug. The shorting plug shorts pins 4 and 7 of J3.
- 9. Turn power OFF and reassemble.

**FIGURE D.2** 



P.C. BOARD



## HOW TO USE TROUBLESHOOTING GUIDE

### A WARNING

Service and Repair should only be performed by Lincoln Electric Factory Trained Personnel. Unauthorized repairs performed on this equipment may result in danger to the technician and machine operator and will invalidate your factory warranty. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed throughout this manual.

This Troubleshooting Guide is provided to help you locate and repair possible machine malfunctions. Simply follow the three-step procedure listed below.

#### Step 1. LOCATE PROBLEM (SYMPTOM).

Look under the column labeled "PROBLEM (SYMP-TOMS)". This column describes possible symptoms that the machine may exhibit. Find the listing that best describes the symptom that the machine is exhibiting.


#### Step 2. POSSIBLE CAUSE.

The second column labeled "POSSIBLE CAUSE" lists the obvious external possibilities that may contribute to the machine symptom.

#### Step 3. RECOMMENDED COURSE OF ACTION

This column provides a course of action for the Possible Cause, generally it states to contact your local Lincoln Authorized Field Service Facility.

If you do not understand or are unable to perform the Recommended Course of Action safely, contact your local Lincoln Authorized Field Service Facility.



## A CAUTION

## TROUBLESHOOTING

Observe all Safety Guidelines detailed throughout this manual

	Safety Guidelines detailed throughout	
PROBLEMS (SYMPTOMS)	POSSIBLE CAUSE	RECOMMENDED COURSE OF ACTION
Err 81	Digital Display Models Error Codes Motor overload, long term.	<ol> <li>Check that the electrode slides easily through the gun and cable.</li> <li>Remove tight bends from the gun and cable.</li> <li>Check that the spindle brake is not too tight.</li> <li>Verify a high quality electrode is being used.</li> <li>Wait for the error to reset and the motor to cool (approximately 1 minute).</li> </ol>
Err 82	Motor overload, short term.	<ol> <li>Check that motor can turn freely when idle arm is open.</li> <li>Verify that the gears are free of debris and dirt.</li> </ol>
	Output Problems	
The feeder does power up - no dis- play, no cold feed.	<ul><li>nected or is a poor electrical connection. (Across the arc models)</li><li>2. The power source is OFF.</li><li>3. The circuit breaker for the wire feeder on power source have tripped. (control cable models)</li></ul>	<ol> <li>Connect the work sense lead to the work in a location free of dirt, rust and paint.</li> <li>Turn ON the power source.</li> <li>Reset the circuit breakers.</li> <li>Tighten, repair or replace the con- trol cable.</li> </ol>
(Across the Arc models) The wire feeder power up but there is no output when the trigger is pulled. The shielding gas is flowing and the drive rolls turn.	2. The contactor has failed.	<ol> <li>Verify the contactor coil connec- tions.</li> <li>Replace the contactor.</li> </ol>
No shielding gas.	<ol> <li>The gas supply is OFF or empty.</li> <li>The gas hose is cut or crushed.</li> <li>The flow meter valve is closed.</li> <li>Dirt or debris is in the solenoid.</li> <li>There is a loose solenoid connection.</li> <li>The solenoid has failed.</li> </ol>	<ol> <li>Verify the gas supply is ON and flowing.</li> <li>Route the gas hose so it avoids sharp corners and make sure nothing is on top of it. Repair or replace damaged hoses.</li> <li>Open the flow meter valve.</li> <li>Apply filtered shop at 80psi to the solenoid to remove dirt.</li> <li>Remove the cover and check that all connections are in good condi- tion.</li> <li>Replace solenoid.</li> </ol>

## 



Observe all Safety Guidelines detailed throughout this manual				
PROBLEMS	POSSIBLE	RECOMMENDED		
(SYMPTOMS)	CAUSE	COURSE OF ACTION		
Inconsistent wire feeding or wire not feeding but drive rolls turning.	<ol> <li>The gun cable is kinked and/or twisted.</li> <li>The wire is jammed in the gun and cable.</li> </ol>	<ol> <li>Keep the gun cable as straight as possible. Avoid sharp corners or bends in the cable.</li> <li>Remove the gun from the wire feeder and pull the jammed wire out of the gun and cable.</li> <li>Blow dirt out of the liner with low pressure (40psi or less). Replace the liner if worn.</li> <li>Use only clean electrode. Use quality electrode, like L-50 or L-56 from Lincoln Electric.</li> <li>Replace the contact tip.</li> <li>Verify the proper parts are installed.</li> <li>Adjust the tension arm per the Instruction Manual. Most elec- trodes feed well at a tension arm setting of "3".</li> <li>Verify the spool of wire moves with minimal effort.</li> <li>Replace the drive rolls if worn or filled with dirt.</li> </ol>		
Wire feed speed consistently oper- ates at the wrong value. The speed changes when the wire feed speed knob is adjusted.	improperly. 2. The wrong gear is installed in the wire drive.			
The wire feed speed stuck at 200- 300 in/min and there is no change when the wire feed speed knob is adjusted.		<ol> <li>Verify all of the tachometer leads are properly connected.</li> <li>Replace the motor and tachome- ter assembly.</li> </ol>		

## **A** CAUTION


## TROUBLESHOOTING


Observe all Safety Guidelines detailed throughout this manual

(SYMPTOMS)         CAUSE         COURSE OF ACT           Variable or "hunting" arc.         1. Wrong size, worn and/or melted contact tip.         1. Replace the contact tip.           2. Worn work cable or poor work connection.         1. Replace the contact tip.         2. Verify all work and elect nections are tight and cables are in good co Clean/replace as necess           3. Wrong polarity.         4. The gas nozzle is extended beyond the contact tip or the wire stickout is too long.         3. Adjust polarity to the rece do procedure.           5. Poor gas shielding on processes requiring gas.         5. Check gas flow and Remove or block so drafts.           Poor arc starts with sticking or "blast-offs", weld porosity, narrow and ropy looking bead.         1. Improper procedures or tech- niques.         1. See "Gas Metal Arc Guide" (GS-100).	ION
<ul> <li>Variable or "hunting" arc.</li> <li>1. Wrong size, worn and/or melted contact tip.</li> <li>2. Worn work cable or poor work cables are in good car cabl</li></ul>	
Variable or "hunting" arc.1. Wrong size, worn and/or melted contact tip.1. Replace the contact tip.2. Worn work cable or poor work connection.2. Verify all work and elect nections are tight and cables are in good ca Clean/replace as necess3. Wrong polarity.3. Wrong polarity.3. Wrong polarity.4. The gas nozzle is extended beyond the contact tip or the wire stickout is too long.4. Adjust the gas nozzle an the stickout to 3/8 to 1/2 is5. Poor gas shielding on processes requiring gas.5. Check gas flow and Remove or block so drafts.Poor arc starts with sticking or "blast-offs", weld porosity, narrow1. Improper procedures or tech- niques.1. See "Gas Metal Arc Guide" (GS-100).	
2. Worn work cable or poor work connection.2. Verify all work and elect nections are tight and cables are in good ca 	
connection.nections are tight and cables are in good co Clean/replace as necess3. Wrong polarity.Adjust polarity to the rec ed procedure.4. The gas nozzle is extended beyond the contact tip or the wire stickout is too long.Adjust the gas nozzle an the stickout to 3/8 to 1/2 is5. Poor gas shielding on processes requiring gas.5. Check gas flow and Remove or block so drafts.Poor arc starts with sticking or "blast-offs", weld porosity, narrow1. Improper procedures or tech- niques.1. See "Gas Metal Arc Guide" (GS-100).	
3. Wrong polarity.3. Adjust polarity to the received procedure.4. The gas nozzle is extended beyond the contact tip or the wire stickout is too long.3. Adjust the gas nozzle and the stickout to 3/8 to 1/2 is stickout is too long.5. Poor gas shielding on processes requiring gas.5. Check gas flow and Remove or block so drafts.Poor arc starts with sticking or "blast-offs", weld porosity, narrow1. Improper procedures or techniques.1. See "Gas Metal Arc Guide" (GS-100).	that the ondition.
<ul> <li>4. The gas nozzle is extended beyond the contact tip or the wire stickout is too long.</li> <li>5. Poor gas shielding on processes requiring gas.</li> <li>5. Check gas flow and Remove or block so drafts.</li> <li>Poor arc starts with sticking or "blast-offs", weld porosity, narrow</li> <li>1. Improper procedures or tech- niques.</li> <li>1. See "Gas Metal Arc Guide" (GS-100).</li> </ul>	
requiring gas.Remove or block so drafts.Poor arc starts with sticking or "blast-offs", weld porosity, narrow1. Improper procedures or tech- niques.1. See "Gas Metal Arc Guide" (GS-100).	
"blast-offs", weld porosity, narrow niques. Guide" (GS-100).	
	Welding

## **A** CAUTION









WARNING	<ul> <li>Do not touch electrically live parts or electrode with skin or wet clothing.</li> <li>Insulate yourself from work and ground.</li> </ul>	• Keep flammable materials away.	• Wear eye, ear and body protection.
AVISO DE PRECAUCION	<ul> <li>No toque las partes o los electrodos bajo carga con la piel o ropa moja- da.</li> <li>Aislese del trabajo y de la tierra.</li> </ul>	<ul> <li>Mantenga el material combustible fuera del área de trabajo.</li> </ul>	<ul> <li>Protéjase los ojos, los oídos y el cuerpo.</li> </ul>
French ATTENTION	<ul> <li>Ne laissez ni la peau ni des vête- ments mouillés entrer en contact avec des pièces sous tension.</li> <li>Isolez-vous du travail et de la terre.</li> </ul>	<ul> <li>Gardez à l'écart de tout matériel inflammable.</li> </ul>	<ul> <li>Protégez vos yeux, vos oreilles et votre corps.</li> </ul>
German WARNUNG	<ul> <li>Berühren Sie keine stromführenden Teile oder Elektroden mit Ihrem Körper oder feuchter Kleidung!</li> <li>Isolieren Sie sich von den Elektroden und dem Erdboden!</li> </ul>	• Entfernen Sie brennbarres Material!	<ul> <li>Tragen Sie Augen-, Ohren- und Kör- perschutz!</li> </ul>
ATENÇÃO	<ul> <li>Não toque partes elétricas e elec- trodos com a pele ou roupa molha- da.</li> <li>Isole-se da peça e terra.</li> </ul>	<ul> <li>Mantenha inflamáveis bem guarda- dos.</li> </ul>	<ul> <li>Use proteção para a vista, ouvido e corpo.</li> </ul>
Japanese 注意事項	<ul> <li>通電中の電気部品、又は溶材にヒ フやぬれた布で触れないこと。</li> <li>施工物やアースから身体が絶縁されている様にして下さい。</li> </ul>	<ul> <li>燃えやすいものの側での溶接作業 は絶対にしてはなりません。</li> </ul>	● 目、耳及び身体に保護具をして下 さい。
Chinese 警告	<ul> <li>●皮肤或濕衣物切勿接觸帶電部件及 銲條。</li> <li>●使你自己與地面和工件絶縁。</li> </ul>	●把一切易燃物品移離工作場所。	●佩戴眼、耳及身體勞動保護用具。
Korean 위 험	<ul> <li>전도체나 응접봉을 젖은 형겁 또는 피부로 절대 접촉치 마십시요.</li> <li>모재와 접지를 접촉치 마십시요.</li> </ul>	●인화성 물질을 접근 시키지 마시요_	●눈, 귀와 몸에 보호장구를 착용하십시요.
Arabic	<ul> <li>لا تلمس الاجزاء التي يسري فيها التبار</li> <li>الكهريائي أو الالكترود بجلد الجسم أو</li> <li>بالعلايس المبللة بالماء.</li> <li>ضع عازلا على جسمك خلال العمل.</li> </ul>	<ul> <li>ضع المواد القابلة للاشتعال في مكان بعيد.</li> </ul>	فتع أدوات وملابس واقيةً على عينيك وأذنيك. وجسمك.

READ AND UNDERSTAND THE MANUFACTURER'S INSTRUCTION FOR THIS EQUIPMENT AND THE CONSUMABLES TO BE USED AND FOLLOW YOUR EMPLOYER'S SAFETY PRACTICES.

SE RECOMIENDA LEER Y ENTENDER LAS INSTRUCCIONES DEL FABRICANTE PARA EL USO DE ESTE EQUIPO Y LOS CONSUMIBLES QUE VA A UTILIZAR, SIGA LAS MEDIDAS DE SEGURIDAD DE SU SUPERVISOR.

LISEZ ET COMPRENEZ LES INSTRUCTIONS DU FABRICANT EN CE QUI REGARDE CET EQUIPMENT ET LES PRODUITS A ETRE EMPLOYES ET SUIVEZ LES PROCEDURES DE SECURITE DE VOTRE EMPLOYEUR.

LESEN SIE UND BEFOLGEN SIE DIE BETRIEBSANLEITUNG DER ANLAGE UND DEN ELEKTRODENEINSATZ DES HER-Stellers. Die Unfallverhütungsvorschriften des Arbeitgebers sind ebenfalls zu beachten.

	·		
<ul> <li>Keep your head out of fumes.</li> <li>Use ventilation or exhaust to remove fumes from breathing zone.</li> </ul>	<ul> <li>Turn power off before servicing.</li> </ul>	<ul> <li>Do not operate with panel open or guards off.</li> </ul>	WARNING
<ul> <li>Los humos fuera de la zona de respiración.</li> <li>Mantenga la cabeza fuera de los humos. Utilice ventilación o aspiración para gases.</li> </ul>	<ul> <li>Desconectar el cable de ali- mentación de poder de la máquina antes de iniciar cualquier servicio.</li> </ul>	<ul> <li>No operar con panel abierto o guardas quitadas.</li> </ul>	AVISO DE PRECAUCION
<ul> <li>Gardez la tête à l'écart des fumées.</li> <li>Utilisez un ventilateur ou un aspirateur pour ôter les fumées des zones de travail.</li> </ul>	<ul> <li>Débranchez le courant avant l'entre- tien.</li> </ul>	<ul> <li>N'opérez pas avec les panneaux ouverts ou avec les dispositifs de protection enlevés.</li> </ul>	French ATTENTION
<ul> <li>Vermeiden Sie das Einatmen von Schweibrauch!</li> <li>Sorgen Sie für gute Be- und Entlüftung des Arbeitsplatzes!</li> </ul>	<ul> <li>Strom vor Wartungsarbeiten abschalten! (Netzstrom völlig öff- nen; Maschine anhalten!)</li> </ul>	<ul> <li>Anlage nie ohne Schutzgehäuse oder Innenschutzverkleidung in Betrieb setzen!</li> </ul>	German WARNUNG
<ul> <li>Mantenha seu rosto da fumaça.</li> <li>Use ventilação e exhaustão para remover fumo da zona respiratória.</li> </ul>	<ul> <li>Não opere com as tampas removidas.</li> <li>Desligue a corrente antes de fazer serviço.</li> <li>Não toque as partes elétricas nuas.</li> </ul>	<ul> <li>Mantenha-se afastado das partes moventes.</li> <li>Não opere com os paineis abertos ou guardas removidas.</li> </ul>	Portuguese ATENÇÃO
<ul> <li>● ヒュームから頭を離すようにして 下さい。</li> <li>● 換気や排煙に十分留意して下さい。</li> </ul>	<ul> <li>メンテナンス・サービスに取りか かる際には、まず電源スイッチを 必ず切って下さい。</li> </ul>	●パネルやカバーを取り外したままで機械操作をしないで下さい。	Japanese 注意事項
●頭部遠離煙霧。 ●在呼吸區使用通風或排風器除煙。	● 維修前切斷電濟	●儀表板打開或沒有安全罩時不準作 業。	Chinese 警告
<ul> <li>얼굴로부터 용접가스를 멀리하십시요.</li> <li>호흡지역으로부터 용접가스를 제거하기 위해 가스제거기나 통풍기를 사용하십시요.</li> </ul>	● 보수전에 전원을 차단하십시요.	● 판넬이 열린 상태로 작동치 마십시요.	<sup>Korean</sup> 위 험
<ul> <li>ابعد رأسك بعيداً عن الدخان.</li> <li>استعمل التهوية أو جهاز ضغط الدخان للخارج</li> <li>لكي تبعد الدخان عن المنطقة التي تنتض فيها.</li> </ul>	الظع التيار الكهربائي قبل القيام بأية صيائة	لا تشغل هذا الجهاز اذا كانت الاغطية الحديدية الواقية ليست عليه.	Arabic

## LEIA E COMPREENDA AS INSTRUÇÕES DO FABRICANTE PARA ESTE EQUIPAMENTO E AS PARTES DE USO, E SIGA AS PRÁTICAS DE SEGURANÇA DO EMPREGADOR.

使う機械や溶材のメーカーの指示書をよく読み、まず理解して下さい。そして貴社の安全規定に従って下さい。

請詳細閱讀並理解製造廠提供的説明以及應該使用的銀捍材料,並請遵守貴方的有関勞動保護規定。

이 제폼에 동봉된 작업지침서를 숙지하시고 귀사의 작업자 안전수칙을 준수하시기 바랍니다.

اقرأ بتمعن وافهم تعليمات المصنع المنتج لهذه المعدات والمواد قبل استعمائها واتبع تعليمات الوقاية لصاحب العمل.

#### CUSTOMER ASSISTANCE POLICY

The business of The Lincoln Electric Company is manufacturing and selling high quality welding equipment, consumables, and cutting equipment. Our challenge is to meet the needs of our customers and to exceed their expectations. On occasion, purchasers may ask Lincoln Electric for advice or information about their use of our products. We respond to our customers based on the best information in our possession at that time. Lincoln Electric is not in a position to warrant or guarantee such advice, and assumes no liability, with respect to such information or advice. We expressly disclaim any warranty of any kind, including any warranty of fitness for any customer's particular purpose, with respect to such information or advice. As a matter of practical consideration, we also cannot assume any responsibility for updating or correcting any such information or advice once it has been given, nor does the provision of information or advice create, expand or alter any warranty with respect to the sale of our products.

Lincoln Electric is a responsive manufacturer, but the selection and use of specific products sold by Lincoln Electric is solely within the control of, and remains the sole responsibility of the customer. Many variables beyond the control of Lincoln Electric affect the results obtained in applying these types of fabrication methods and service requirements.

Subject to Change – This information is accurate to the best of our knowledge at the time of printing. Please refer to www.lincolnelectric.com for any updated information.



THE LINCOLN ELECTRIC COMPANY 22801 St. Clair Avenue • Cleveland, OH • 44117-1199 • U.S.A. Phone: +1.216.481.8100 • www.lincolnelectric.com