
-CK WORLDWIDE INC.-


WARRANTY:

CK Worldwide, Inc. warrants products manufactured by CK Worldwide, Inc. to be free of defects in materials and workmanship. CK Worldwide, Inc. limits this warranty to replacement of the product or parts thereof and excludes liability for injury, property damage or economic loss attributable to product use or misuse. In any event, CK Worldwide, Inc. will only be responsible for its products when used with accessory items manufactured by CK Worldwide, Inc.

INSTALLATION: Before using this torch, - tighten regulator, hose and power cable fittings with proper wrenches. Using small pliers, securely tighten all knurled hose fittings (Slide the torch handle back for access to the torch connections). Purge the regulator and TIG torch with inert gas at 20 cubic feet per hour. Following these steps will ensure contamination free welds. Repeat this procedure whenever torch or regulator fittings have been detached.

CONNECTION DIAGRAM:






INFORMATION CHART:

| Electrode Diameter in inches (mm) | Cup Size | WELDING CURRENT (AMPS) - TUNGSTEN TYPE | | | | ARGON FLOW - FERROUS METALS | | ARGON FLOW - ALUMINUM | |
|--|-------------|--|-----------------|--------------|-------------------|--------------------------------|------------------------------|------------------------------|------------------------------|
| | | AC Pure | AC Thoriated | DCSP Pure | DCSP Thoriated | Standard Body (Liters) | Gas Lens Body (Liters) | Standard Body (Liters) | Gas Lens Body (Liters) |
| .020 (0.50) | 4 or 5 | 5 - 15 | 5 - 20 | 5 - 15 | 5 - 20 | 5-8 (3-4) | 5-8 (3-4) | 5-8 (3-4) | 5-8 (3-4) |
| .040 (1.00) | 4 or 5 | 10 - 60 | 15-80 | 15 - 70 | 20 - 80 | 5-10 (3-5) | 5-8 (3-4) | 5-12 (3-6) | 5-10 (3-5) |
| 1/16 (1.60) | 4, 5 or 6 | 50 - 100 | 70 - 150 | 70 - 130 | 80 - 150 | 7-12 (4-6) | 5-10 (3-5) | 8-15 (4-7) | 7-12 (4-6) |
| 3/32 (2.40) | 6, 7 or 8 | 100 - 160 | 140 - 235 | 150 - 220 | 150 - 250 | 10-15 (5-7) | 8-10 (4-5) | 10-20 (5-10) | 10-15 (5-7) |
| 1/8 (3.20) | 7, 8 or 10 | 150 - 210 | 220 - 325 | 220 - 330 | 240 - 350 | 10-18 (5-9) | 8-12 (4-6) | 12-25 (6-12) | 10-20 (5-10) |
| 5/32 (4.00) | 8 or 10 | 200 - 275 | 300 - 425 | 375 - 475 | 400 - 500 | 15-25 (7-12) | 10-15 (5-7) | 15-30 (7-14) | 12-25 (6-12) |
| 3/16 (4.80) | 8 or 10 | 250 - 350 | 400 - 525 | 475-800 | 475-800 | 20-35 (10-17) | 12-25 (6-12) | 25-40 (12-19) | 15-30 (7-14) |
| 1/4 (6.40) | 10 | 325 - 700 | 500 - 700 | 750 - 1000 | 700 - 1100 | 25-50 (12-24) | 20-35 (10-17) | 30-55 (14-26) | 25-45 (12-21) |

TUNGSTEN PREPARATION:




Shape tungsten by grinding Remove sharp point to leave a truncated point with a flat spot. Diameter of flat spot determines The included angle determines weld bead shape and size. Generally, as the included angle increases. penetration increases and bead

Use a 60 Grit or finer aluminum

GRINDING PREPARATION: | EXTENSION INSTRUCTION: STANDARD PARTS General Purpose: 3 x Diameter from end of cup.



GAS LENS PARTS General Purpose:



Ball tip by arcing on clean metal at low current DCRP (EP) then slowly increase current to form the desired ball diameter.

CAUTION:

Personal harm will result from touching the hot parts of a TIG torch without insulative protection, or from looking directly or indirectly at an arc or reflected arc. At no time should bare skin be exposed to a welding arc.





TIG TORCH MANUAL



MR70 MICRO TORCH

TECHNICAL INFORMATION

RATING @ 100% DUTY CYCLE: 70 AMP ACHF OR DCSP

COOLING METHOD: GAS COOLED

ACCESSORY ITEMS REQUIRED FOR COMPLETE INSTALLATION:

HEAD ACCESSORIES: MICRO TORCH POWER CABLE ADAPTOR: 105Z57 (15PCA)

MODEL SELECTOR - TORCH PACKAGES


| HEAD STYLE | CABLE STYLE | CABLE LENGTH | PART# | |
|---------------|----------------|--------------------|---------|--|
| Rigid Head - | 1 Diago | 12-1/2 ft. (3.8 m) | MR712SF | |
| w/o valve | 1 Piece | 25 ft. (7.6 m) | MR725SF | |

IMPORTANT!! READ AND UNDERSTAND THE INFORMATION CONTAINED IN THIS MANUAL BEFORE OPERATING THE EQUIPMENT!

CK WORLDWIDE INC. 3501 "C" ST. N.E. **AUBURN. WA. 98002**

PHONE: (253) 854-5820 PHONE: (800) 426-0877 FAX: (253) 939-1746

www.ckworldwide.com ck@ckworldwide.com



PARTS LIST:

ACCESSORIES:

| PART NUMBER DESCRIPTION | PART NUMBER | DESCRIPTION |
|-------------------------|---------------------------------------|---------------------------------|
| MR70 Torch Body, 70 Amp | 15PCA (105Z57) | Power Cable Adapter |
| 140H | Safe-Loc G SL-2 SL2-25 SL2-35 SL2-25M | Quick Connectors TWECO DINSE 25 |
| MRTI | | |

HEAD INSTALLATION: The insulating tube(MRTI) extends beyond the torch neck intentionally. Apply pressure when first installing the head. This will create a flair in the insulating tube to make a positive seal to the head.

2





Part # TS10

TURBO-SHARP® X is an enclosed electrode grinder, which eliminates grinding-dust exposure to both the user and the environment.

TURBO-SHARP® X includes a metal carrying case containing:

- Standard head for diameters: .040"(1.0mm), 1/16"(1.6mm), 3/32"(2.4mm) and 1/8"(3.2mm)
- Accessory for stationary mounting
- Adapter for vacuum cleaning
- Pen style electrode holder
- Multi-functional cover
- Tools for assembling and replacement of grinding wheel
- User instructions





3